

COBY DVD615

IMPORTANT PLEASE READ!

COMMON TROUBLESHOOTING ISSUES

ISSUE #1 NO PICTURE

Make sure your TV is turned to the correct Video line (AV Input/Video Input 1,2,3.etc. Consult the TV manufacture if you need help setting the TV to the correct Video line. If you are going through a cable box, contact your cable provider or the cable manufacture. Once your TV is turned to the correct video line, you should see the "COBY" logo.

ISSUE #2 ROLLING, COLORLESS SCREEN

Make sure the Yellow Video wire is connected into the Video connection on the DVD player and on the TV

ISSUE #3 HAD A COLOR PICTURE, NOW RECEIVING A BLACK AND WHITE OR A ROLLING SCREEN

The DVD has been set to the incorrect broadcast system. Press the N/P button on the remote to select the correct broadcast system (make sure you do not have a disk in the tray while pressing the N/P button). NTSC is for the United States TV broadcast system

ISSUE #4 NO SOUND OR BACK GROUND SOUND WITH NO VOICES

Make sure the Red and White wire is connected into your TV "AUDIO IN".

Make sure the Red and White wire is connected into the Front-L & Front-R.

Make sure the DVD player Audio setting Analog Out AC3 is set to 2 Channel.

ISSUE #5 PICTURE FADES DARK TO LIGHT

You cannot connect the DVD through your VCR, TV/VCR combo, Cable or Satellite.

If you cannot connect directly to the TV via a Yellow Video input, then you will need to purchase an RF Modulator and a four-foot Coaxial wire at your local electronics store.

ISSUE #6 HAD PICTURE, NOW RECEIVING A BLACK OR BLUE SCREEN

The DVD player may be set to Progressive Scan Mode. You will need to change the Video mode from Progressive Scan to Composite. Make sure you DO NOT have a disk in the tray. Point the remote control directly at the DVD player, and then press the MODE button 2-3 times.

ISSUE #7 WHY CANT I GET THE MICROPHONE TO WORK

- 1) Turn your TV to the correct Video line. Once your TV is turned to the correct video line, you should see the "COBY" logo.
- 2) Connect the Microphone into Mic1 or MIC2
- 3) Turn the microphone switch to the "ON" position
- 4) In front of the DVD player, adjust the MIC and Volume knob to "MAX"
- 5) On the DVD remote control, press the "MIC" button until "ON" appears and then press the "KARAOKE" button until "Stereo" appears.

If you are still having difficulty setting up your new DVD player, please contact Customer Service or Technical Support, Monday-Friday 8:00 AM – 11:00 PM EST, Saturday and Sunday 9:00 AM – 11:00 PM EST. You can also reach us online at customerservice@cobyusa.com or techsupport@cobyusa.com

1-800-681-2629 OR 718-416-3197